


DIGITAL PIANO

Owner's Manual



INFORMATION FOR YOUR SAFETY!

THE FCC REGULATION WARNING (for USA)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Unauthorized changes or modification to this system can void the user's authority to operate this equipment.

CAUTION

The normal function of the product may be disturbed by Strong Electro Magnetic Interference. If so, simply reset the product to resume normal operation by following the owner's manual. In case the function could not resume, please use the product in other location.

PRECAUTIONS

PLEASE READ CAREFULLY BEFORE PROCEEDING

Please keep this manual in a safe place for future reference.

Power Supply

Please connect the designated AC adaptor to an AC outlet of the correct voltage.

Do not connect it to an AC outlet of voltage other than that for which your instrument is intended.

Unplug the AC power adaptor when not using the instrument, or during electrical storms.

Connections

Before connecting the instrument to other devices, turn off the power to all units. This will help prevent malfunction and / or damage to other devices.

Location

Do not expose the instrument to the following conditions to avoid deformation, discoloration, or more serious damage:

- Direct sunlight
- Extreme temperature or humidity
- Excessive dusty or dirty location
- Strong vibrations or shocks
- Close to magnetic fields

Interference with other electrical devices

Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions.

Cleaning

Clean only with a soft, dry cloth.

Do not use paint thinners, solvents, cleaning fluids, or chemical-impregnated wiping cloths.

Handling

Do not apply excessive force to the switches or controls.

Do not let paper, metallic, or other objects into the instrument. If this happens, remove the electric plug from the outlet. Then have the instrument inspected by qualified service personnel.

Disconnect all cables before moving the instrument.

Contents

Panel Description

Front Panel.....	4
Pedal.....	4
Rear Panel.....	5

Setup

Setup Guide.....	6
------------------	---

Connections

Connecting a pair of Headphones.....	9
Connecting an Audio Equipment.....	9
Connecting an MP3/CD Player.....	9
Connecting a Computer.....	9

Quick Start

Power Supply.....	10
Adjusting the Master Volume.....	10
Playing the Demo.....	10
Playing the Voices.....	10
Playing the Songs.....	11
Recording.....	11

Playing the Voices

Playing a Voice.....	12
Playing Two Voices Simultaneously.....	12
Playing Different Voices with Both Hands.....	12
Voice Volume.....	13
Playing a Voice Demo.....	13
Touch Response.....	13
Transpose.....	14
Tune.....	14
Pedal Resonance.....	14
Metronome.....	15
Tempo.....	15

DSP Effect

Reverb.....	16
Chorus.....	16
D.A.S. (Dynamic Acoustic System).....	16

Song

Play the Songs.....	17
Practice the Songs.....	17

Song Recording

Prepare Recording.....	18
Start Recording.....	18
Stop Recording.....	18
Play back Recording.....	18
Delete Recording.....	18

Duet

.....	19
-------	----

Twinova

.....	19
-------	----

MIDI Out Channel

.....	20
-------	----

Beep Tone

.....	20
-------	----

Troubleshooting

.....	21
-------	----

Specifications


.....	21
-------	----

Appendices

Voice List.....	22
Song List.....	22
Demo List.....	22
MIDI Implementation Chart.....	23

Panel Description

Front Panel



1. [METRO] Button

Press it to turn the Metronome on or off.

2. [PLAY] Button

Start or stop playing the recorded song.
Press [METRO] and [PLAY] together to enter Recording mode.

3. [DUAL] Button

Press it to turn the Dual function on or off.

4. [LOWER] Button

Press it to turn the Lower function on or off.

5. [SONG] Button

Press it to enter Song mode.

6. [START/STOP] Button

Start or stop playing a song.

7. [FUNCTION] Button

Press and hold it to access secondary functions of other keys.

When [FUNCTION] button is pressed:

8. [VOICE] Keys

Press to select a preset voice.

9. [V-DEMO] Key

Press it to start or stop playing a voice demo.

10. [TWINOVA] Key

Press it to turn the Twinova function on or off.

11. [RES.] Key

Press it to turn the Pedal Resonance on or off.

12. [DUET] Keys

Press to turn the Duet function on or off, or to select a Duet type.

13. [DEMO] Key

Press it to start or stop playing the demo.

14. [SONG] Keys

Press to select a song.

15. [TEMPO] Keys

Press to edit the Tempo value.

Pedal

34. Soft Pedal


Press the soft pedal, the notes played on the keyboard will sound softer.

35. Sostenuto Pedal


Press the sostenuto pedal, the notes played before you step on the pedal will have a sustain effect.

36. Sustain Pedal

Press the sustain pedal, the notes played on the keyboard will have a longer sustain. The sustain pedal also supports half-pedal operation. Perform with the sustain pedal to achieve a smooth sustain effect.



Panel Description



When [FUNCTION] button is pressed:

16. [METRO] Keys

Press to set the Metronome type.

17. [TRANSP.] Key

Press it to edit the Transpose setting.

18. [TUNE] Key

Press it to edit the Tune setting.

19. [TOUCH] Key

Press it to edit the Touch response setting.

20. [REVERB] Key

Press it to edit the Reverb setting.

21. [CHORUS] Key

Press it to edit the Chorus setting.

22. [METRO-VOL] Key

Press it to edit the Metronome volume.

23. [R1-VOL] Key

Press it to edit the Upper voice volume.

24. [R2-VOL] Key

Press it to edit the Dual voice volume.

25. [L-VOL] Key

Press it to edit the Lower voice volume.

26. [SPLIT] Key

Press it to edit the split point setting.

27. [OCTAVE] Key

Press it to edit Twinova octave setting.

28. [MIDI OUT] Key

Press it to edit the MIDI out channel setting.

29. [<]/[>] Keys

Press to adjust the parameters.

30. [REC] Keys

Press to select a user song to record or to play back.

31. [BEEP] Key

Press it to turn the Beep tone on or off.

32. [D.A.S.]Key

Press it to turn the D.A.S. function on or off.

33. [POWER] Switch

Turn the power on or off.

34. [VOLUME] Knob

Adjust the master volume.

Rear Panel

37. USB Jack

Connect to a computer.

38. AUX OUT Jack


Connect to an external audio equipment.

39. AUX IN Jack

Connect an external audio source, such as an MP3 or CD player.

40. DC IN Jack

Connect the specified power adaptor.




Setup

This section contains information about setting up your instrument and preparing to play. Please go through this section carefully before turning the power on.

Setup Guide

To assemble the stand, you will need a Phillip's screwdriver (not supplied). Check that all the parts listed below are included before proceeding.




1.	Piano body
2.	Left leg
3.	Right leg
4.	Pedal box
5.	Big back board
6.	Screw 6 X 50 (4 pcs)
7.	Hand screw (2 pcs)
8.	Screw M6 X 18 (4 pcs)
9.	Screw 4 X 15 (4 pcs)
10.	Screw cap (4 pcs)
11.	Pedal cable
12.	AC power adaptor




Setup


- A. Put the pedal box (4) in between the left and right leg components (2&3), use 4 pieces of screws (8) (2 on each side) to fix the legs onto the foot pedal unit, then cover the screw caps (10) on top (2 on each side) (Make sure the components are in the right direction before installing.).



- B. Place the big back board against the stand completed in Step A, then use screw (9) and screw (6) to fix it to the stand.




- C. Put the piano body on the top of the assembly finished in Step B, then use screws (6) and hand screw (7) to fix it.



Setup

D. Connect the pedal cable to the pedal jack at the rear bottom of the piano. The setup is completed, now the piano is ready to connect to power supply.



Connections

Connecting a pair of Headphones


Plug a pair of standard stereo headphones here for private practice or late-night playing.

Jack 1: When headphones are connected, sound can be heard from the headphones and speakers.

Jack 2: When headphones are connected, the internal speakers will be muted, and the sound can only be heard from the headphones.

Note:

To avoid the risk of hearing loss, do not use headphones at high volume level for a long period of time.




Connecting an Audio Equipment

The AUX OUT jack delivers the output of the instrument to external audio equipment such as a keyboard amplifier, stereo sound system, mixing console, or recording interface.

Use an audio cable to connect the AUX OUT jack of the instrument to the INPUT jack of the external audio equipment.

Notes:


1. Turn off the power to all devices before connecting or disconnecting external equipment.
2. To avoid damaging the speakers, set the master volume level to minimum before turning on the power.



Connecting an MP3/CD Player

The AUX IN jack receives audio signals from an external audio source such as an MP3 or a CD player.

Use an audio cable to connect the AUX IN jack of the instrument to the OUTPUT jack of an MP3/CD player. The instrument's speakers will play the music transmitted from the external player, and you can play along.




Connecting a Computer

Use a standard USB cable to connect the USB jack of the instrument to the USB port of a computer.

With USB, you can save a keyboard performance to the computer or use the instrument to play back music played on the computer.

Note:


Do not set the USB MIDI device to be both input and output simultaneously when configuring the software on your computer. Otherwise, the sound will be overlapped when playing the keyboard.



Quick Start

Power Supply

1. Before connecting to power supply, please set the [POWER] switch to "OFF" and set the master volume level to minimum.
2. Connect the power adaptor to the DC IN jack on the rear panel.
3. Plug the power adaptor into an appropriate AC outlet.
4. Press the [POWER] switch. The button indicator lights up, indicating the instrument is powered on.
5. When you are ready to turn the instrument off, press and hold the [POWER] switch for a second. The button indicator will turn off.



Notes:


1. In order to save energy, the instrument will automatically shut down after 30 minutes when not in use. To turn off this function, press and hold the key A0 (the first key to the left of the keyboard), then turn on the power.
2. For your safety, please unplug the instrument when it is not in use or during a thunderstorm.

Adjusting the Master Volume

Rotate the [VOLUME] knob clockwise to increase the master volume or counter-clockwise to decrease it. Adjust to set the desired volume level.

Note:


If the speakers do not produce sound, please check if the master volume is set too low or if headphones are plugged into Jack 2.



Playing the Demo

The instrument features a professional demo. Please refer to the Demo List for details.

1. Press and hold [FUNCTION], then press the key marked [DEMO] to start playing the demo. Repeat this operation to stop the demo.
2. During demo playback, press the [START/STOP] button to stop playing and exit Demo mode.




Playing the Voices

The instrument features a variety of exceptionally realistic voices. Please refer to the Voice List for details.

1. Press and hold [FUNCTION], then press one of the VOICE keys to select a preset voice.
2. Each VOICE key has two preset voices. Press a VOICE key once to select the first preset voice, press this key again to select the second preset voice.

Note:


If you select the first voice of a key, pressing another key will select the first voice of that key, in the same way, if you select the second voice of a key, pressing another key will select the second voice of that key.



Playing the Songs

The instrument features a variety of preset songs. Please refer to the Song List for details.

1. Press the [SONG] button to enter Song mode. All songs start playing in a loop.
2. Press and hold [FUNCTION], then press one of the SONG keys to select a desired song.
3. Press the [START/STOP] button to stop playing. Press this button again to play the current song in a loop.






Note:

When using the keys marked SONG [0–9] to select a song, you will need to press 2 keys total. For example, press 0,8 in sequence to select the “08” song.

Recording

You can record and save your keyboard performance as a user song on the instrument.

1. Press [METRO] and [PLAY] buttons at the same time, then use the keys marked REC [1–5] to select a user song to which the recording will be saved.
2. It then enters Recording standby mode. The button indicator for [START/STOP] will blink. Now you can set the instrument voice, song, tempo and so on.
3. Press the [START/STOP] button or simply play the keyboard to start recording. The button indicators for [METRO] and [PLAY] will stay lit.
4. During recording, if you press [METRO] and [PLAY] buttons at the same time, recording will stop and be saved. The button indicators for [METRO] and [PLAY] will turn off.
5. To play back a user song, press and hold [PLAY], then use the keys marked REC [1–5] to select the desired user song.
6. After selecting a user song, the button indicator for [PLAY] will light up. Press this button again to start the playback.
7. To stop the playback, press the [PLAY] button.
8. After selecting a user song for playback, if you press [METRO] and [PLAY] buttons at the same time, it will delete the selected user song.



Note:

If you do not select a user song for recording or playback, it will automatically use the same user song in the last operation. If you restart the instrument, it will select the first user song by default.

Playing the Voices


The instrument features a variety of exceptionally realistic voices. Please refer to the Voice List for details.

Playing a Voice

1. Press and hold [FUNCTION], then press one of the VOICE keys to select a preset voice.
2. Each VOICE key has two preset voices. Press a key once to select the first preset voice, press this key again to select the second preset voice.
3. Play the keyboard to use the selected voice for performance.

Note:

If you select the first voice of a VOICE key, pressing another key will select the first voice of that key, in the same way, if you select the second voice of a key, pressing another key will select the second voice of that key.




Playing Two Voices Simultaneously

The Dual function allows two different voices to be layered together, creating a more full and rich sound.

1. Select an upper voice.
2. Press the [DUAL] button to turn on the Dual function. The button indicator will light up.
3. Press and hold [DUAL], then press one of the VOICE keys to select a dual voice.
4. Play the keyboard and you will hear two different voices playing together.
5. Press the [DUAL] button again to turn off this function. The button indicator will turn off.

Note:


When the Lower and Dual functions are in use, only the right hand area will play the dual voice.



Playing Different Voices with Both Hands

The Lower function splits the keyboard into two areas so as to create different voices for each of your hands. The left hand voice is the lower voice.

1. Select an upper voice.
2. Press the [LOWER] button to turn on the Lower function. The button indicator will light up.
3. Press and hold [LOWER], then press one of the VOICE keys to select a lower voice.
4. Play the keyboard with both hands and you will hear two different voices from the left and right hand areas.
5. Press the [LOWER] button again to turn off this function. The button indicator will turn off.





Playing the Voices

Split point

The key that splits the keyboard into the left and right hand areas is called "split point". The default split point is F#3 (34) , however, you can assign it to any other key.

1. Press and hold [FUNCTION], then press the key marked [SPLIT] to edit the split point, and then tap a key on the keyboard to assign the split point to that key.





2. Release the [FUNCTION] button to exit the edit mode.

Voice Volume

You can adjust separately the volume of the upper voice, the dual voice and the lower voice.

1. Press and hold [FUNCTION], then press the key marked [R1-VOL] to edit the volume of the upper voice.





2. In edit mode, press and hold [FUNCTION], then use the keys marked SETTING [<]/[>] to adjust the volume range from 0 to 15.

3. In edit mode, press and hold [FUNCTION], then press SETTING [<] and [>] keys at the same time to reset the volume to default.

4. Set the volume of the dual voice and lower voice in the same way.

Playing a Voice Demo

1. In Voice mode, press and hold [FUNCTION], then press the key marked [V-DEMO] to start playing the current upper voice demo.





2. During demo playback, press and hold [FUNCTION], then press the [V-DEMO] key to stop playing. You can also press the [START/STOP] button to stop the playback.

Touch Response


The touch response feature allows you to expressively control the voice level based on your playing dynamics, just as on an acoustic instrument. There are 5 types of touch settings (Off, 1–5). The default setting is 3.

1. Press and hold [FUNCTION], then press the key marked [TOUCH] to edit the touch setting.



2. In edit mode, press and hold [FUNCTION], then use the keys marked SETTING [<]/[>] to change the setting.

3. In edit mode, press and hold [FUNCTION], then press SETTING [<] and [>] keys at the same time to restore the default setting.




Parameter	Description
OFF	Fixed
1	Soft 1
2	Soft 2
3	Medium
4	Hard 1
5	Hard 2

Playing the Voices

Transpose

The transpose function allows the overall pitch of the instrument to be transposed up or down by a maximum of one octave in semitone steps.

1. Press and hold [FUNCTION], then press the key marked [TRANSP.] to edit the transpose setting.
2. In edit mode, press and hold [FUNCTION], then use the keys marked SETTING [<]/[>] to change the setting range from -12 to +12.
3. In edit mode, press and hold [FUNCTION], then press SETTING [<] and [>] keys at the same time to restore the default setting "00".





Notes:

1. For example, set the transpose value to -05 or 007, you will hear "G" pitch when playing the "C" keys.
2. Transpose setting applies to the accompaniment and the entire keyboard voice.

Tune

This function adjusts the pitch of the entire keyboard in 2-cent increments over a range of ± 50 (100 cents).

1. Press and hold [FUNCTION], then press the key marked [TUNE] to edit the tune setting.
2. In edit mode, press and hold [FUNCTION], then use the keys marked SETTING [<]/[>] to change the setting.
3. In edit mode, press and hold [FUNCTION], then press SETTING [<] and [>] keys at the same time to restore the default setting "00".





Parameter	Description
Tune >	To raise the overall pitch by 1.
Tune <	To lower the overall pitch by 1.

Pedal Resonance

When a piano voice is selected, pressing the sustain pedal will add string resonance effect to the notes you play. The string resonance effect faithfully recreates the resonance from the strings and soundboard of an acoustic grand piano.

1. Press and hold [FUNCTION], then press the key marked [RES.] to turn this function on or off.
2. This function is turn on by default.



Notes:

1. The chorus effect will be disabled when pedal resonance is in use.
2. There may be a slight pause in the sound if you switch pedal resonance on/off while performing.


Playing the Voices

Metronome

The metronome provides a steady beat to help you practice at a preset tempo.

Turn the metronome on or off.



Press the [METRO] button to turn the metronome on or off.



When the metronome is in use, the button indicator for [START/STOP] will flash in sync with the metronome sound. (Red for downbeat and blue for upbeat). To adjust the metronome tempo, please refer to Tempo for details.



Set the metronome beat.

Press and hold [FUNCTION], then use the keys marked METRO [0–6] to change the metronome beat. There are 6 beat types: 0, 2–6.



Set the metronome volume.

1. Press and hold [FUNCTION], then press the key marked [METRO–VOL] to edit the metronome volume.
2. In edit mode, press and hold [FUNCTION], then use the keys marked SETTING [<]/[>] to change the volume range from 0 to 15.
3. In edit mode, press and hold [FUNCTION], then press SETTING [<] and [>] keys at the same time to reset the volume to default.







Note:

The metronome is not available in Song mode.

Tempo

Each song, duet pattern and so on is preset with a default or standard tempo, but you can change the tempo range from 30 to 280.

1. Press and hold [FUNCTION], then use the keys marked TEMPO [<]/[>] to change the tempo value.
2. Press and hold [FUNCTION], then press the TEMPO [<] and [>] keys at the same time to restore the default tempo “120”. In Song mode, it will reset to the default song tempo.
3. Press and hold [FUNCTION], then press the keys marked TEMPO [0–9] to set the tempo value. For example, press 2, 1, 4 in sequence to enter a tempo value of 214.
4. Alternatively, press and hold [FUNCTION], then tap the key marked [TAP] twice to get the desired tempo. The instrument will start the metronome sound at the tapping speed.



Parameter	Description
TAP	Set the tempo at the tapping speed.
Tempo >/<	Increase/decrease the tempo value by 1.
0–9	Enter a specific tempo value (Press 3 keys total to enter a tempo value).

Notes:



1. When using the keys marked TEMPO [0-9] to set the tempo value, you will need to press 3 keys total. For example, press 0, 6, 4 in sequence to enter a tempo value of 64.
2. In standby mode, if the times you press the [TAP] key equal to that of the metronome beat, the instrument will start the metronome sound at the speed of the last two presses.

DSP Effect

The DSP effects will add ambiance and depth to your performance in a variety of ways.

Reverb



1. Press and hold [FUNCTION], then press the key marked [REVERB] to edit the reverb setting.
2. In edit mode, press and hold [FUNCTION], then use the keys marked SETTING [<]/[>] to change the reverb type.
3. In edit mode, press and hold [FUNCTION], then press the SETTING [<] and [>] keys at the same time to restore the default reverb type "2 Hall".



Parameter	Description
OFF	Reverb effect is disabled.
1	Room
2	Hall
3	Church
4	Delay
5	Pan delay

Chorus

1. Press and hold [FUNCTION], then press the key marked [CHORUS] to edit the chorus setting.
2. In edit mode, press and hold [FUNCTION], then use the keys marked SETTING [<]/[>] to change the chorus type.
3. In edit mode, press and hold [FUNCTION], then press the SETTING [<] and [>] keys at the same time to restore the default chorus type "OFF".



Parameter	Description
OFF	Chorus effect is disabled.
1	Chorus 1
2	Chorus 2
3	Chorus 3
4	Flanger
5	Rotary

D.A.S. (Dynamic Acoustic System)

The loudness of sound perceived by human ears over the frequency spectrum is different. As the audio volume decreases, human ears' sensitivity to extreme high and low frequencies will decline. As a result, the audio may seem to become 'thin' sounding at low volumes, losing bass and treble.




The D.A.S. function, will dynamically adjust the sound of the instrument according to the overall volume for better sound balance, giving you a more clear, natural and rich sound.

Turn the D.A.S. function on or off

Press and hold [FUNCTION], then press the key marked [D.A.S.] to turn this function on or off.

Note:

The D.A.S. function is turned on by default.



Song

The instrument features a variety of preset songs. Please refer to the Song List for details.


Play the Songs

1. Play all songs in a loop.
Press the [SONG] button to enter Song mode. The button indicator will light up. All preset songs start playing in a loop.
2. Play the selected song in a loop.
When the playback stops, press the [START/STOP] button to play the current song in a loop.
3. Select a song.
Press and hold [FUNCTION], then use the keys marked SONG [<]/[>] or [0–9] to select a desired song.

Notes:

When using the keys marked SONG [0–9] to select a song, you will need to press 2 keys total. For example, press 0,8 in sequence to select the “08” song.


4. Stop the playback.
During song playback, press the [START/STOP] or [SONG] button to stop playing.




Practice the Songs

All preset songs can be practiced with melody-off.

1. Press and hold [FUNCTION], then press the key marked SONG [L] to mute the left hand melody. You can practice the left hand melody of the song. Repeat this operation to activate the left hand melody.



2. In the same way, press and hold [FUNCTION], then press the key marked SONG [R] to mute the right hand melody. You can practice the right hand melody of the song.




Song Recording

You can record and save your keyboard performance as a user song on the instrument, and then play it back.

Prepare Recording

1. Before recording starts, you need to select a user song to which the recording will be saved. Press [METRO] and [PLAY] buttons at the same time, then use the keys marked REC [1–5] to select a user song.
2. It then enters Recording standby mode. The button indicator for [START/STOP] will blink. Now you can set the instrument voice, tempo and so on.



Start Recording

In Recording standby mode, press the [START/STOP] button or simply play the keyboard to start recording. The button indicators for [METRO] and [PLAY] will stay lit.




Note:

If the current user song has data, the data will be overwritten after recording.


Stop Recording

1. During recording, if you press [METRO] and [PLAY] buttons at the same time, recording will stop and be saved. The button indicators for [METRO] and [PLAY] will turn off.
2. During recording, if the memory gets full, recording will automatically stop and be saved. The button indicators for [METRO] and [PLAY] will turn off.




Play back Recording

1. After recording, press and hold [PLAY], then use the keys marked REC [1–5] to select the desired user song.
2. Press the [PLAY] button to start playback. The button indicator will light up.
3. To stop playback, press the [PLAY] button again. The button indicator turns off.



Delete Recording

1. Press and hold [METRO] and [PLAY] buttons, then turn on the power. This operation will delete all user songs.
2. After selecting a user song for playback, if you press [METRO] and [PLAY] buttons at the same time, it will delete the selected user song.



Note:

The saved user songs will not be lost after power off.

Duet

The Duet function will enrich your performance. Simply play a chord with your left hand, and the instrument will play a preset duet pattern and produce a beautiful melody.

Turn the duet function on or off.

Press and hold [FUNCTION], then press the key marked DUET [ON/OFF] to turn this function on or off.

Select a duet pattern.

Press and hold [FUNCTION], then press the key marked DUET [<]/[>] to select a desired duet pattern. There are 32 duet patterns. The default setting is "01".


Note:

Each voice is matched with a preset duet pattern, so when you change a voice, the default duet pattern will change as well.

Set the duet split point

When the Duet function is in use, the keyboard will be split into two areas. You can play chords in the left hand area, and play melody in the right hand area. The default split point is the same as in the lower function: F#3 (34). You can assign the split point to any other key.

1. Press and hold [FUNCTION], then press the key marked [SPLIT] to edit the split point, and then tap a key on the keyboard to assign the split point to that key.
2. Release the [FUNCTION] button to exit the edit mode.



Twinova

The Twinova function splits the keyboard into two areas with the same pitch and voice, for the convenience of playing together with a friend or instructor.

Turn the Twinova function on or off.

Press and hold [FUNCTION], then press the key marked [TWINOVA] to turn this function on or off. The default split point is E3 (32). In Twinova mode, the Dual and Lower functions are not available.


Select a voice for Twinova.

The upper voice selected before entering Twinova will become the default voice for both areas. To change the voice, press and hold [FUNCTION], then press one of the VOICE keys.

Set the split point for Twinova.

In Twinova mode, press and hold [FUNCTION], then press the key marked [SPLIT] to edit the split point, and then tap a key (range from C3 to C6) to assign the split point to that key.

Release the [FUNCTION] button to exit the split point edit mode.




Twinova

Set the octave for Twinova.

This function will shift the pitch of the entire keyboard up or down by one octave. This function is available only in Twinova mode. The octave setting will be reset to default when you exit Twinova mode.

1. Press and hold [FUNCTION], then press the key marked [OCTAVE] to edit the octave setting.
2. In edit mode, press and hold [FUNCTION], then use the keys marked SETTING [<]/[>] to adjust the octave value.
3. In edit mode, press and hold [FUNCTION], then press the SETTING [<] and [>] keys at the same time to reset the octave to default "0".





Note:

The Twinova function is not available in Song mode and Demo mode.

MIDI Out Channel



1. Press and hold [FUNCTION], then press the key marked [MIDI OUT] to edit the MIDI Out channel.
2. In edit mode, press and hold [FUNCTION], then use the keys marked SETTING [<]/[>] to set the MIDI Out channel range from 01 to 16.
3. In edit mode, press and hold [FUNCTION], then press the SETTING [<] and [>] keys at the same time to restore the default setting "01".



Beep Tone

The instrument will produce a sound when using the keyboard to change a setting. This function is turned on by default.

To turn off the function, press and hold [FUNCTION], then press the key marked [BEEP].



Troubleshooting

Problem	Possible Cause and Solution
The speakers produce a pop sound whenever the power is turned ON/OFF.	This is normal and no cause for alarm.
Speakers do not produce sound when the keyboard is played.	Check if the master volume is set too low or if headphones are plugged into Jack 2.
There is noise when I use a mobile phone.	Using a mobile phone in close proximity to the instrument may produce interference. To prevent this, turn off the mobile phone or keep it away from the instrument when using.
When connecting to computer, the instrument cannot be recognized.	Check if the USB cable is firmly connected. Try connecting another USB port on the computer. This instrument is plug and play and should work without installing a driver.

Specifications

Keyboard & Display	
Keyboard	88 Graded Hammer-Action Keys with Triple Sensors
Touch Response	5 types, Off
Voices	
Polyphony (max.)	128
Voices	20
Layer	Left, Right1, Right2
Split	Yes
Duo (Twinova)	Yes
Effects	
Reverb	5 types, Off
Chorus	5 types, Off
Performance Enhance	
Duet	32 types
Song & Recording	
Music Library	60 preset songs, with L/R hand learning
Sequencer	5 user songs
Demo	1 piano demo, 20 voice demos
Pitch Adjustment	
Transpose	-12-+12
Octave	-1-+1 (Twinova)
Tuning	-50-+50

Other Functions	
Metronome	0, 2-6
Tempo	30-280
Other control	Voice demo, MIDI out channel, D.A.S.
Connections	
Interaction & Expansion	USB MIDI, PC software
Phones	2 standard stereo
Pedals	Sustain, Soft, Sostenuto
USB	USB MIDI
Input	Standard stereo
Output	Standard stereo
Power Supply	
Power	DC15V / 2500mA
Power Off Protection	Yes
Amplifiers & Speakers	
Amplifiers	20W x 2
Speakers	10W x 2
Dimensions & Weight	
Dimensions LWH (mm)	1320 x 440 x 853
Weight (kg)	41.5

* All specifications and appearances are subject to change without notice.

Voice List

No.	Voice Name
1	GrandPiano
2	GrandPiano 2
3	Honky Tonk Piano
4	E.Piano 1
5	E.Piano 2
6	Harpsichord
7	Clavi
8	Music Box
9	Vibraphone
10	Drawbar Organ

11	JazzOrgan
12	Percussive Organ
13	Rock Organ
14	PipeOrgan
15	Accordion
16	Harmonica
17	Nylon Guitar
18	Soprano Sax
19	String Ensembles
20	Flute

Song List

No.	Song Name
1	The Entertainer
2	Rialto Ripples (Rag)
3	Neapolitan Song
4	Waltzes
5	Turkish March
6	Schos Doll's Dance No. 2
7	Minuet In D Major
8	Inquietude
9	Italian Polka
10	Moment Musical
11	Prelude In C-Sharp Major
12	The Happy Farmer
13	The Rag-Time Dance
14	Piano Sonata In C Major, K.330. III
15	Mazurka
16	Prelude In E Major
17	Piano Sonata In A Major, K.331. I
18	Waltz For Piano In G-Sharp Minor
19	Gavotte
20	L' Arabesque
21	Austria Variation
22	Schos Doll's Dance No. 7
23	To A Wild Rose
24	Gavotte I
25	Waltz
26	Minuet In G Major (BWV Anh. 116)
27	Innocence
28	Tchaikovsky Waltz
29	Salut d' Amour
30	Barcarolle

31	Robot Doll
32	Consolation
33	2-Part Invention #13 In A Minor.B.W. Iii
34	Minuet In G Major (BWV Anh. 114)
35	Barcarolle
36	Norwegian Dance No.2
37	Moseta Dance
38	The Small Gathering
39	The Return
40	The Wagtail
41	Bulie Dance
42	Tender Blossom
43	Grace
44	Cherish The Memories
45	Chopsticks
46	Four Little Swans
47	Progress
48	Eclogue
49	The Limpid Stream
50	Brave Cavalier
51	The Chatterbox
52	Tarantella
53	Frankness
54	Tender Grieving
55	The Farewell
56	The Chase
57	Habanera
58	Prelude In C Major
59	Fountain
60	Fur Elise

Demo Song

No.	Song Name
1	Fantasia

MIDI Implementation Chart

Function		Transmitted	Recognized	Remarks
Basic Channel	Default	1ch	ALL	
	Changed	1–16ch	1–16ch	
Mode	Default	x	3	
	Messages	x	3	
	Altered	*****	x	
Note Number	Note	0–127	0–127	
	:True voice	*****	0–127	
Velocity	Note on	○ 9nH,V=1–127	○ 9nH,V=1–127	
	Note off	x (9nH,V=0)	○(9nH,V=0; 8nH,V=0–127)	
After Touch	key's	x	x	
	Ch's	x	x	
Pitch Bend		x	○	
Control Change	0	○	○	Bank Select
	1	x	○	Modulation
	5	x	○	Portamento Time
	6	○	○	Data Entry
	7	○	○	Volume
	10	x	○	Pan
	11	x	○	Expression
	64	○	○	Sustain Pedal
	65	x	○	Portamento ON/OFF
	66	○	○	Sostenuto Pedal
	67	○	○	Soft Pedal
	80	○	○	Reverb Program
	81	○	○	Chorus Program
	91	○	○	Reverb Level
	93	○	○	Chorus Level
	120	○	○	All Sound Off
	121	x	○	Reset All Controllers
123	○	○	All Notes Off	
Program Change	:True	○ *****	○ 1–127	
System Exclusive		x	○	
System Common	:Song Position	x	x	
	:Song Select	x	x	
	:Tune	x	x	
System Real Time	:Clock	○	x	
	:Commands	x *1	x *1	
Aux Messages	:LOCAL ON/OFF	x	x	
	:Active sense	x	○	
	:Reset	x	○	
Notes: *1 When the accompaniment is started, an FAH message is transmitted. When the accompaniment is stopped, an FCH message is transmitted.				

- Mode 1: OMNI ON, POLY
- Mode 2: OMNI ON, MONO

- Mode 3: OMNI OFF, POLY
- Mode 4: OMNI OFF, MONO

- : YES
- x: NO

